

Instructions for use

## Description

Melting flux.

## Indication

For all casting alloys (solidus less than 1000°C/1832°F) when melting alloys with an open flame or induction.

## Instructions for use

Add in small quantity of Borax to the alloy before melting. Borax is an efficient method of avoiding oxidation of the alloy during melting. Borax can be used to glaze crucibles.

## Particular risks and safety precautions

T



**Toxic**

**Contains: Borax**

R60 May impair fertility.

R61 May cause harm to the unborn child.

S53 Avoid exposure – obtain special instructions before use.

S45 In case of accident or if you feel unwell, seek medical advice immediately (show the label where possible).

Presentation  
080232 Borax 100 ml



Rx only